

BIOS Settings for EL339-b Motherboard


This procedure applies only to systems with the EL339-b Motherboard. If your System Computer has a different motherboard, check <http://service.globalvr.com> for updated information.

If you are comfortable using the CMOS Setup Utility, connect a keyboard to the computer and press the **DEL** key during boot to run the Utility. Select **Load Optimized Defaults** from the **Main** Menu first, and then check all of the settings shown in the table below. For more help, refer to the detailed instructions that follow.

Menu	Item	Setting
Main	Load Optimized Defaults	(Press Enter and then press Y)
Standard CMOS Features	Date	(Set current date)
	Time	(Set to local time)
	Halt On	No Errors
Advanced BIOS Features	First Boot Device	CDROM
	Second Boot Device	Hard Disk
	Third Boot Device	Disabled
Integrated Peripherals	SuperIO Device	(Press Enter to open sub-menu)
SuperIO Device (Sub-Menu)	PWRON After PWR-Fail	On


Important: Your screens may not look exactly like the screens in the pictures that follow, and some settings in the pictures may be different from your system. **Do not change any settings that are not specifically described in this document.**

1. Press the **DEL** key during boot. The CMOS Setup Utility Main Menu will appear:
2. Use the Arrow keys (\uparrow \downarrow \rightarrow \leftarrow) to select **Load Optimized Defaults**, and press **Enter**.
Press **Y** and **Enter** when prompted to confirm the change.



3. Use the Arrow keys to highlight **Standard CMOS Features**, and then press **Enter**. A screen similar to the following will appear:

4. Use the Arrow keys to select **Date**; the month will be highlighted.
Use the **Page Up** and **Page Down** keys to set the month. Press the Right Arrow (→) key to move to the day, and set it the same way. Repeat for the year.




5. Use the Arrow keys to select **Time**. Set the local time the same way you set the date.
Verify **Drive A** is set to **None**.

6. Use the Arrow keys to highlight the setting for **Halt On**.
Use the **Page Up** and **Page Down** keys to change the setting to **No Errors**.
Press **ESC** to go back to the Main Menu.

7. Now use the Arrow keys to highlight **Advanced BIOS Features** and press **Enter**. A screen similar to the following will appear:


8. Use the Arrow keys to highlight the setting for **First Boot Device**.
Use the **Page Up** and **Page Down** keys to change the setting to **CDROM**.




9. Set **Second Boot Device** to **Hard Disk** and **Third Boot Device** to **Disabled** the same way.
Press **ESC** to go back to the Main Menu.

10. Now use the Arrow keys to highlight **Integrated Peripherals** and press **Enter**. A screen similar to the following will appear:

11. Use the Arrow keys to highlight the setting for **SuperIO Device** and press **Enter**. The SuperIO Device Screen will appear.



- In the SuperIO Device Screen, use the Arrow keys to highlight the setting for **PWRON After PWR-Fail**. Use the **Page Up** and **Page Down** keys to change the setting to **On**. Press **ESC** twice if you wish to go back to the Main Menu to check any more settings.



- Now that all settings are correct, press **F10**. The following prompt will appear:

Save to CMOS and EXIT (Y/N)? Y

- Make sure "Y" shows at the end of the prompt (use the arrow keys to change, if necessary), and press **Enter** to save the settings and exit.