

Aliens™ Extermination to Paradise Lost™ Standard Conversion Kit

Document Part #: 040-0164-01

This kit converts an Aliens™ Extermination Standard cabinet to Paradise Lost™. The procedure consists of installing the Game Dongle and Software, and replacing the cabinet artwork.

Note: Keep your *Aliens™ Extermination System Manual* for service, troubleshooting, and hardware reference. The *Paradise Lost™ Operation Manual* in the kit contains operation and gameplay information.

Kit Contents

| Part Number | Qty | Description |
|-----------------|-----|---|
| 040-0164-01 | 1 | Conversion Kit Instructions (This Document) |
| 040-0165-01 | 1 | Paradise Lost Operation Manual |
| 040-0166-01 | 1 | Software Restore Guide for Paradise Lost with 27" CRT Monitor |
| 050-0126-01 | 1 | Paradise Lost System Recovery Disk, Version 2.0 |
| 050-0133-01 | 1 | Paradise Lost Game Install Disks (4 CDs) |
| 050-0134-01 | 1 | Paradise Lost 27" Monitor Patch Disk |
| PL27-AW-01 | 1 | Left & Right Upper Side Panel Decal |
| PL32-AW-01 | 1 | Left Side Panel Decal |
| PL32-AW-02 | 1 | Right Side Panel Decal |
| PL32-AW-03 | 1 | Kick Panel Decal |
| PL32-AW-05 | 1 | Backlit Instruction Panel |
| PL32-AW-06 | 1 | Backlit Marquee |
| PL32-AW-07 | 1 | Control Panel Decal |
| PL32-AW-08 | 1 | Left Gun Base Decal |
| PL32-AW-09 | 1 | Right Gun Base decal |
| PL32-AW-10 | 1 | Top Left Gun Base Decal |
| PL32-AW-11 | 1 | Top Right Gun Base Decal |
| USB-KQRTG-HL-PL | 1 | Paradise Lost Game Dongle |

Tools Required

- Exacto® Knife with New Blade
- Screwdriver with Assorted Torx Security Bits
- Vinyl Application Squeegee (or Similar Tool) for Smoothing Decals

Install the Game Dongle

Remove the Aliens Extermination Game Dongle from the USB port in the computer and insert the Paradise Lost Game Dongle from the kit.

Install the Software



The software installation must be performed in the order described below. If you do not install the disks in the correct order, you may need to start over again.

Software installation takes about 40 minutes.

1. Run the System Recovery Disk

1. With the cabinet powered ON, open the CD-ROM drive and insert the CD labeled **System Recovery Disk** (Version 2.0 or later is required). Power the cabinet OFF and then ON. The computer will boot from the CD, and you will see the Symantec™ Ghost installer screen on the monitor.
2. After about 8 minutes, when you are prompted, remove the CD and turn the cabinet OFF and then ON. (**Do not** insert another disk yet!)
3. When the computer reboots, you will see a series of processing screens. After about 3-4 minutes the computer will automatically reboot.
4. When the computer reboots, you will briefly see a message saying "Insert Game Disk 1", followed by the GLOBAL VR logo on the screen. If you have a 27" CRT monitor, ignore this message and proceed to run the **Monitor Patch Disk**. (If you have an LCD monitor, do not run the Patch Disk.)

2. Run the Monitor Patch Disk (27" Monitor Only)

Important: This Patch Disk is only for cabinets with 27" CRT Monitors. **DO NOT USE** in cabinets with LCD Monitors.

1. Insert the **Monitor Patch Disk** in the drive. The disk will run automatically.
2. After a few seconds, when prompted, remove the Patch Disk and insert the CD labeled **Game Install Disk 1 of 4**. **DO NOT** reboot.

3. Run the Game Install Disks

1. **Game Install Disk 1 of 4** will run automatically. You will see the Installer screen as the software copies files. After about 6—7 minutes the computer will eject the CD and prompt you to insert Disk #2.

2. Insert the CD labeled **Game Install Disk 2 of 4**. The disk will run automatically (do not reboot). After about 6—7 minutes the computer will eject the CD and prompt you to insert Disk #3.
3. Insert the CD labeled **Game Install Disk 3 of 4**. The disk will run automatically (do not reboot). After about 6—7 minutes the computer will eject the CD and prompt you to insert Disk #4.
4. Insert the CD labeled **Game Install Disk 4 of 4**. The disk will run automatically (do not reboot). After about 6—7 minutes the computer will reboot.
5. After about 1 minute more, the Initial Calibration screen will appear. Remove the CD from the drive.
6. Press the **TEST/BACK** button to open the Operator Menu. Select **Controller Test** and follow the onscreen prompts to calibrate both guns (see your Operation Manual for more information).

Note: The Initial Calibration screen will be displayed until you open the Operator Menu.

4. Set Up and Test the Game

1. Use the Operator Menus to change any desired settings.
2. Play a game and use both guns to verify proper operation. (Press the **SELECT** button in Attract Mode to insert Service Credits for testing the game.)

Replace the Marquee

1. From the back of the marquee, remove the three (3) wood screws and five (5) nuts with washers that secure the silk-screened plastic marquee in place.
2. Remove the piece of wood behind the Alien's head at the center of the marquee if it does not come off with the silk-screened plastic.
3. Install the new marquee from the kit. It consists of artwork and clear plastic.

Install the Cabinet Artwork

Refer to Figure 1 and Figure 2 for placement of the cabinet artwork. Figure 3 shows the finished cabinet.

If existing cabinet decals are in good condition, with no cracks or tears, apply the new decals over old decals. Otherwise remove the existing decals and clean off any adhesive that remains on the cabinet. Make sure the cabinet surface is clean so the new decals will adhere properly.

1. Carefully align the Upper and Lower Side Panel decals so that they cover the entire panel. Additional alignment instructions are printed on the lower side panel decals. Trim off excess material with a sharp Exacto knife, using the edge of the cabinet as a guide.
2. Apply and trim the kick panel decal the same way.
3. Reach through the coin door to remove the control panel buttons. Gently rock the micro switch and lamp housing to the side to remove it, and then unscrew the button retaining ring.
4. The Gun Base and Control Panel decals are cut to be an exact fit. Align them carefully to completely cover the existing decals.
5. Replace the control panel buttons.
6. Remove the four (4) screws that hold the Instruction Panel in place and replace the artwork.



Figure 1. Installing Main Cabinet Artwork



Figure 2. Installing Control Panel Artwork



Figure 3. Finished Cabinet