



- NOTES:** Wire colors may vary due to harness revisions.
 Sub Button is Flamethrower in some games.
 Action Button is Grenade/Rocket Launcher in some games.