

## JAMMA+ Harness Pinout Diagram for Global Arcade Classics Kit

SOLDER SIDE				COMPONENT SIDE		
Signal	Color	Pin		Pin	Color	Signal
Ground	BLK	A		1	BLK	Ground
Ground	BLK	B		2	BLK	Ground
+5V	RED	C		3	RED	+5V
+5V	RED	D		4	RED	+5V
-5V	BLU	E		5	BLU	-5V
+12V	ORG	F		6	ORG	+12V
Key		H		7		Key
Not Used	WHT-RD	J		8	WHT-BLK	Coin meter 1
Not Used	BLK-GRN	K		9	BLK-YEL	Not Used
Left Speaker -	BLU-RED	L		10	RED-YEL	Left Speaker +
Right Speaker -	BLU-GRN	M		11	RED-BLK	Right Speaker +
Video green	GRN	N		12	RED	Video Red
Video Sync	WHT	P		13	BLU	Video Blue
Service switch	WHT-ORG	R		14	BLK	Video Ground
Not Used	BLK-WHT	S		15	WHT-BRN	Test Switch
Coin 2	BRN-BLK	T		16	YEL-BLK	Coin 1
Player 2 Start	RED-WHT	U		17	RED	Player 1 Start
Player 2 Up	BLU-WHT	V		18	BLU	Player 1 Up
Player 2 Down	GRN-WHT	W		19	GRN	Player 1 Down
Player 2 Left	ORG-WHT	X		20	ORG	Player 1 Left
Player 2 Right	YEL-WHT	Y		21	YEL	Player 1 Right
Player 2 Button 1	BRN-WHT	Z		22	BRN	Player 1 Button 1
Player 2 Button 2	VIO-WHT	Aa		23	VIO	Player 1 Button 2
Player 2 Button 3	GRY-WHT	Ab		24	GRY	Player 1 Button 3
Player 2 Button 4	GRN-YEL	Ac		25	GRN-RED	Player 1 Button 4
Not Used	ORG-BLK	Ad		26	ORG-RED	Not Used
Ground	BLK	Ae		27	BLK	Ground
Ground	BLK	Af		28	BLK	Ground

**Table 1. JAMMA+ Harness Pinouts**

© 2012 GLOBAL VR Inc.