

Panasonic 3D TV Setup

Document Part #: 040-0256-01

Note: These instructions are specific to Panasonic TV Model No. **TC-L47ET5**.

If you are experiencing a problem with the TV, GLOBAL VR recommends resetting the TV to factory defaults and then re-entering all of the settings as described in this section.

Use the remote control and follow the steps below. General instructions for navigating the menus with the remote control are as follows:

- Use the $\Delta \nabla$ buttons on the remote control to highlight an item in a menu.
- Use the $\triangleleft \triangleright$ buttons to change the setting for the highlighted item.
- Press the **OK** button to open a submenu or save a setting.
- Press the **Return** button to exit from a menu or submenu.

Note: Highlighted items are **Yellow** on the menu screens.

1. Before setting up the monitor, the System Computer must be in 1080p and 3D Mode. Press the **Test/Back** button on the Operator Button Panel inside the coin door and confirm or set the following in the Operator Menu:
 - In **Machine Settings: Settings** set **3D Display** to **Enable**
 - In **Diagnostics: Monitor Resolution** set resolution to **1920 x 1080**
2. Press the **MENU** button on the remote control to open the Main menu.
3. Highlight **Setup** in the Main menu and press **OK** to open the Setup menu.
4. Use the ∇ button to scroll down to **Reset to defaults** (it is off-screen when you open the menu) and press **OK**. You will be prompted to create a password. (This is a temporary password that will not be saved by the TV.) Enter a simple 4-digit password (such as 1-1-1-1) with the remote control keys and press **OK**. Enter the password again in the confirmation screen and press **OK**.
5. When you see the **Reset to Defaults** prompt, highlight **Yes** and press **OK**.

6. After you reset the defaults, the following Setup Screens will appear. On each screen, select the setting described below and press **OK** to go to the next screen. To go back a screen, press the **Return** button.

Screen	Setting
Select your language.	English
Select Country where this TV is being used.	U.S.A. (Set this even if located elsewhere.)
Select your viewing environment.	Home Use
Do you use a cable, satellite, or fiber optic box with this TV?	Yes
Which wiring method is used to connect your box to the TV?	AV IN
What is connected to HDMI 1?	Leave all entries on this screen blank. Use the ▽ key to highlight Next and press OK
Network Settings	Set Later
Set clock	Use the ▽ key to highlight Next and press OK . (The game does not use TV date and time settings.)

7. When you see the **Setup is complete** message, press **OK** to exit.
8. Press the **3D** button on the remote control to put the TV in 3D mode. Read the 3D warning message. Where it says, "Would you like to display this message again later?" Highlight **No** and press **OK**.
9. Press the **MENU** button on the remote control to open the Main menu again.
- Note:** The picture must be set to 3D before doing step 10.
10. Highlight **Picture** in the Main menu and press **OK**. Use the ▽ button to scroll down to **Aspect adjustments** (it is off-screen when you open the menu) and press **OK**. Do the following steps in the Aspect Adjustments menu:
- Use the ◀ ▶ buttons to set **Screen Format** to **FULL**.
 - Use the ◀ ▶ buttons to set **HD Size** to **Size 2** (**Note:** The TV will hide the menu when you highlight this setting so you can see how your selection looks. If you do not set Size 2 the Insert Coins message will be off-screen).
 - Press **Return** to go back to the Picture menu.
11. Highlight **Picture mode** in the Picture menu and use the ◀ ▶ buttons to set it to **Vivid**.
12. Press **Return** to go back to the Main menu.
13. Highlight **Setup** in the Main menu and press **OK** to open the Setup menu.
14. Highlight **3D Settings** in the Setup menu and press **OK**. Do the following steps in the 3D Settings menu:
- Use the ◀ ▶ buttons to set **Auto Detect 3D** to **Auto 2**.
 - Use the ◀ ▶ buttons to set **3D Signal Notification** to **Off**.
 - Press **Return** to go back to the Setup menu.