Setting the Computer BIOS (CMOS)

This procedure applies only to the Asus P5PE-VM Motherboard.

If you are comfortable using the BIOS Setup Utility, connect a keyboard, reboot the game, and press the **DEL** key during boot to enter the CMOS Setup Utility. Select **Load Setup Defaults** from the Exit Menu, and then change the settings shown in the table below.

Detailed instructions for changing the settings follow.

Menu	Sub-Menu	Item	Setting

© 2007 Global VR, Inc.